

PROGRAMMING RCBL RADIATORS

Once installed and connected (please press the switch on the side of the unit), the radiator is on **STAND-BY** position. Please press the STAND-BY button to turn the radiator ON.

To access the programming menu, press the **MENU**. button for 3 seconds.

If you wish to change the menu language, press the **HAND** button until the word displayed is in English.

When **HOUR** displayed, press OK in order to select the current time. Press the **UP/DOWN** buttons, select the hour and press OK to confirm. Select the minutes with the **UP/DOWN** buttons, and press OK.

Then **DAY** will be displayed. Select the current weekday. Press OK (**dd:Mo**) and with the **UP/DOWN** buttons select the current day and press OK to confirm.

Then, we choose the comfort temperature **t**^o**C**, press OK and select the desired Comfort temperature with the UP/DOWN buttons. Press OK.

tº E is displayed, this is the Economy temperature, which should always be at least 3 degrees less than the Comfort temp. In order to choose the economy temperature, we press OK and we select the desired temperature with the UP/DOWN buttons. Press OK to confirm.

Your radiator has 7 pre-programmed plans that you can look up on the instructions manual. In order to select it, **PLAN** will be displayed, press OK to enter the PLAN menu and with the UP/DOWN buttons please select the plan that adapts the better to your needs, then press OK. The timing schedule of that particular program will be displayed, press **MENU** to finish.

The room temperature will be displayed. Your radiator is now programed. Please make sure that the light under the display is either on the Sun (Comfort temperature) or on the Moon (Economy Temperature).

CONFIGURE YOUR PLAN TO YOUR NEEDS - PLCF

Haverland's radiators allow setting a plan that adapts to your needs. We will start programming the Comfort periods from Monday to Friday (L-V). The rest of the time our program will leave the radiator on Economy temperature.

P1=07:00 to 08:00

P2= 21:00 to 23:00

P3= 00:00 to 00:00

We press **MENU** for 3 seconds. Pressing the **UP/DOWN** buttons we choose inside the menu the **PLAN** option and press **OK**. On the screen we see **PLO1**. We search the bespoke plan **PLCF** pressing the UP/DOWN buttons, and press **OK**.

We choose the starting time for the **first comfort period (red sun light ON)** from Monday to Friday (L-V will be ON) with the UP/DOWN buttons **07:00.** Once selected (hour and minutes) we press OK.

Now we choose the finishing time for the first period (P1), with the UP/DOWN buttons we select **08:00 (green moon light ON)**.

This period will set the program on Economy temperature from 00:00 until 07:00; at 07:00 the radiator will change to Comfort and it will stay on that temperature until 08:00, when it will change again to Economy until the next period.

We repeat the same process for P2; first we set 21:00 whenever the SUN is on, the start of our second period. Then, press OK and set 23:00 (MOON on), the end of our period.

If you don't want to configure more comfort periods, you must bear in mind that the period P3 should stay 00:00 – 00:00, and we press OK so the period works correctly. If on the opposite you wish to configure another period, you must repeat the same steps as in the first period.

In order to program the weekend period (S-D) you must repeat the same steps we followed before. When you finish your programming please press **MENU** and make sure that the HAND light is off (if it's ON you should press the HAND button)

When the temperature of the room is displayed, you will see on the bottom of the screen either the sun light on(red) or the moon light (green). If the sun is on, the programming is on COMFORT temperature. If it's on the moon, it's on the economy temperature.

If you wish to re-set the hours of the PLCF program, you will have to access the menu again and repeat the same steps as before.