

How to program LODEL RA ECON

In order to set the programming on the LODEL radiator you will need to turn on the radiator, then press the PROG button for 3 seconds, the clock will be displayed. Please set the current time and date with the + or - buttons. Please press PROG to change from the hour to the minutes, once set press PROG again and you will see a scale of numbers displayed on the top. That's the day of the week.

Please press + or - to select the current day of the week (1 for Monday, 2 for Tuesday and so on) and press PROG,

The programming will be displayed. You can set 3 different temperatures on the day, the Sun will be the Comfort temperature, displayed as two bars at the bottom of the display (highest temperature); the half moon is the Economy Temperature which is displayed with the top bar (medium temperature) and the snowflake is the Antifreeze temperature which is showed as the bottom bar (5/7 degrees).

If you wish to have Comfort temperature at 10:00 you will need to set Economy or Antifreeze temperature until that time. Please press the Half moon button or Snowflake button to select the desired temperature at 00:00 and press the +. You will now need to set the temperature for 01:00 and so on. If you wish to return to a previous time, press the - button. Once reached 23:00 press PROG to change the day (From Monday to Tuesday for example).

Once you finish the Programming the room temperature will be displayed and you will need to see the bars at the bottom of the display. If you only see a Sun/Moon/Snowflake please press the PROG button to select the Programming mode.

To select the desired temperature just click on the button of the temperature you wish to change and press the + or - button to adjust the temperature.